

Strong Arm™ Vent Support

Model numbers:

525-1622V (with Lock Blocks)

525-162PBV (with PEX bend Lock Blocks)

Tools Needed: Slotted screwdriver or 9/16" nut driver,
Phillips screwdriver



Assembly Instructions:

- 1.** Secure bracket assembly to vent pipe with stainless steel band using nut driver or screwdriver
- 2.** From the backside of the Lock Block, push stub out through front of block
- 3.** Position stub outs at desired centerline location
- 4.** Tighten screws on front of Blocks completely.

#IS-525-V

Made in USA

Patent # 8,061,390 Patent # 8,141,831

1-800-821-3944

www.siouxchief.com

**Sioux
Chief** 
MANUFACTURING SINCE 19